

duraflo[®] INSTALLATION GUIDE

FILTERED RIDGE ROLL

Step 1:

Remove ridge cap shingles along entire length of roof.

Step 2:

- a. Measure 1" from ridge peak on each side of ridge. For ridge board construction measure 1-3/4" on each side of ridge.
- b. Snap chalk line along entire length of ridge.
- c. Cut opening in sheathing to create slot. **DO NOT CUT** through roof trusses or ridge board.
- d. Remove sheathing to create slot.
- e. Leave a minimum of 12" of sheathing closed at each end of ridge.



Step 3:

Tack one end of ridge roll, with netting side down, over the slot to hold in place at once end of the ridge. Unroll entire length of vent, pull to remove sags and tack in place so vent is snug and centered over slot. If more than one piece of ridge roll is needed, simply butt the multiple pieces together and tack in place with a nail.

Step 4:

Install ridge cap shingles directly over the ridge roll. Use galvanized roofing nails included in package to secure in place. When properly installed it will fill the 3/4" space between the underside of the cap shingle and the top surface of the roof shingles. Do NOT drive nails through shingle.

Canplas Industries Ltd.
500 Veterans Drive, P.O. Box 1800
Barrie, Ontario, Canada L4M 4V3
Tel. (705) 726-3361
Toll Free 1-800-461-5300
Fax: (705) 726-2186

www.duraflo.com

canplas[®]

21